



**PROTEC**  
**G.T.**

**FORD TRANSIT POWER STEERING PUMP**  
**PART NO: 201003**  
**FACTOR NET: €59.00**

The pump provides hydraulic boost to the steering gear (mechanism that pivots the front wheels) to reduce the driver's turning effort at the wheel.

A power steering pump that's in trouble often emits a high pitched squeal.

To replace your power steering pump— First remove the drive belts and replace if damaged or oil soaked. Undo the high and low pressure lines from the pump body. Have a drip tray ready to catch the fluid. To install the pump reverse the procedure.

After the new pump is fitted, belt reinstalled and tensioned, refill the system with the correct fluid. Rotate the steering wheel from left stop to right stop, preferably with the wheels off the ground and the engine idling. This will release any excess air from the system.

Recheck the fluid level in a few days.

